

Aktiver av/på lys-funksjonen:

GA 203 / GA 403



Har du spørsmål eller trenger du hjelp?
Ring Car-Bo Garasjeporter AS på 55 11 42 10

Activate the on/off light function on the GA203/403:

<p>Program radio channel 3 to the hand transmitters</p>	<div data-bbox="432 159 523 282"> </div> <p>In order to select the desired radio channel <i>r1</i>, <i>r2</i>, <i>r3</i>, or <i>r4</i>, briefly press button TA3...</p> <div data-bbox="432 293 842 394"> <p>...3 x for <i>r3</i></p> </div> <div data-bbox="432 427 544 533"> </div> <p>Hold down the desired button on the remote control for ~3 sec.</p> <div data-bbox="432 566 544 667"> </div> <p>Release button on the remote control. After the teach-in process has been successfully completed, the status display is shown for the door,</p>
<p>Open menu selection window</p>	<div data-bbox="432 734 539 869"> </div> <p>Hold down button TA2 for ~3 sec. until <i>11</i> or <i>12</i> appears on the display.</p>
<p>Go to menu <i>b</i></p>	<div data-bbox="432 943 528 1077"> </div> <div data-bbox="539 943 635 1077"> </div> <p>Press button TA3 or TA1 to switch to the desired menu item.</p> <div data-bbox="432 1122 528 1256"> </div> <p>Press button TA2. → <i>The menu item is selected.</i></p>
<p>Set the value to <i>B</i></p>	<div data-bbox="432 1328 528 1462"> </div> <div data-bbox="539 1328 635 1462"> </div> <p>Press button TA1 or TA3 to change the menu setting.</p>
<p>Exit the menu <i>b</i></p>	<div data-bbox="432 1529 539 1664"> </div> <p>Press button TA2 again to exit the menu item.</p>
<p>Save changes to the menu settings in menu <i>B</i></p>	<div data-bbox="432 1738 528 1872"> </div> <div data-bbox="539 1738 635 1872"> </div> <p>Select menu item <i>B</i> with button TA3 or TA1.</p>
<p>Confirm changes</p>	<div data-bbox="432 1939 539 2074"> </div> <p>Hold down button TA2 for ~3 sec.</p> <p>Successful saving is indicated on the display by:</p> <div data-bbox="1230 2000 1337 2085"> </div>